

M-CON-KNX-s configuration guide

Document number: PO-175-EN Version: 4.0 Date of publication: March 14, 2025

Introduction

The M-CON-KNX-s module enables the Ampio bus to be integrated with KNX bus components. The module has outputs for both the CAN bus and the KNX bus. Please note that the KNX bus must be independently powered and programmed according to KNX standards. Physical and group addresses on the KNX side can be assigned e.g. via the ETS application.

The guide for the Ampio Designer tool applies to M-CON-KNX-s modules of PCB version 2 minimum, while the guide for the Smart Home Configurator is valid for PCB version 1.

Configuration in Ampio Designer

In order to read cyclic data from the KNX bus, a translation list must be configured. With the M-CON-KNX-s module connected, enter its settings using the cog icon and then go to the *KNX* sub-tab.

Functionalities			DEVICES		
Conditions				Q Search	$\oplus $ $\bigcirc $ $\bigcirc $ $\bigcirc $
Parameters		KNX DATA POINT 🔃	NAME 1	VALUE	REMOVE
KNX	0/0/3	9.0		6	temove
	0/0/1	1.0		6	temove
	0/0/4	5.1		6	temove
	0/0/5	1.0		6	temove
	0/0/8	1.0		6	temove
	0/0/12	1.0		6	temove
	0/0/15	1.0		6	temove
	0/0/20	1.0		6	temove
	0/0/21	1.0		6	temove
	0/0/25	1.0			temove

At the bottom, the Monitor window shows the telegrams that the module has received on the KNX bus.

		N	Ionitor		
					< ⊽ ≡ Ξ Ω
SOURCE ADDRESS ঝ	GROUP ADDRESS ঝ	LENGTH 📬	COMMAND ᡝ	DATA 📬	ADD
2.1.2	0/0/3	3	WRITE	0 12 136 (23.20)	Add

This allows us to quickly add a telegram to the list of translations using the *Add* button. The new translation will appear in the *DEVICES* window.

To add a translation manually, select the + icon in the top right corner and enter the group address and the data type according to the KNX standard.

ADDING KNX DEVICE	×
KNX group address	
0/0/1	
KNX data point	
1.0	
Save	

Creation of conditions

In the *LOGIC* tab it is possible to create conditions in both directions, i.e. information can be transmitted from the CAN bus to the KNX bus as well as the other way round.

In order to respond to data from KNX in the Ampio system, a condition has to be created from a virtual device with an address compatible with that of KNX.

#	TRIGGERS
1	Create condition
	Choose device 🗘 🗘
	M-SERV-s (lok15) 1 - M-SERV-s
	test 2f02 - M-CON-KNX-s
	KNX 0/0/3 0/0/3 - KNX
	KNX 0/0/1 0/0/1 - KNX

Assuming this is a binary data type, it is possible, for example, on the basis of a data change on the KNX bus, to change the state of a flag in the Ampio system.

KNX 0/0/1	×	Binary	0	‡ 1. 🔽 🗙	×	Simple	⇒	M-SERV-s	×	Flag 0	ſ	: 13. × 🖶 >	<	Simple 0	Toggle	\$ 0
																Þ

To transmit data from the Ampio system, create a condition, e.g. from a binary flag from any module, and select the M-CON-KNX-s module as the target. In the condition settings, specify the KNX group address, the data type and the interval, i.e. every how many seconds data are to be sent cyclically if the state of the flag does not change. An interval set to 0 results in data not being sent every period of time, but only on a change of state.

△ M-SERV-s	× Flag	û 🚺 14. 🗹 🗙 🕀	× Simple	≎ → test	KNX	¢ 1. ×	Send from CAN	iend 🗘 👩 💆
					() KNX group address	ြဲ KNX datapo	i) nt Interval	(1-65535) s
					0/0/1	1.0	0	

Configuration in the Smart Home Configurator

*from January 2024, the Smart Home Configurator software is no longer being developed. It is recommended to use it only in substantiated instances.

Configuring parameters and single conversions is performed in the Ampio Smart Home configurator (version min. 5.0.0.6822). The first step is to launch the application, wait for the list of devices to load, select M-CON-KNX-s from the list and open *Device parameters*.

💏 An	npio SmartH	lome device	configurator ver. 5.0.0.6847								- []	×
File [Device Pro	ject Utils	Language Connection										
List of	online devi	ces:			_					Your soft	ware is up	to dat	te
Se	arch below:				Search column:	Device nam	ne	\sim	+	Q Se	arch for de	scription	ns
On	MAC	Local	▲ Туре	Name			Pcb	Soft	1		~		
1	9289	9289	U047 M-CON-KNX-s	Modul KNX1			1	2					
										<u>D</u> e	vice monitor	r	
											Q ^o		
										Devio	e <u>c</u> onfigurat	tion	
											۵.		
										Devic	e <u>p</u> aramete	ers	
											$\langle 0 \rangle$		
										<u>N</u> et	work monite	or	
											Q		
										E	nd devices		

Changing the main parameters of the bridge

Devices from the KNX bus will be shown in the CAN bus as virtual devices. Their address will be displayed in the 1100PPAA format, where PP stands for the address prefix, and AA stands for an editable part of the address. In the *Basic* tab you can change the mentioned prefix and edit the physical address that the M-CON-KNX-s bridge uses to send data into the KNX bus. Visible are also the PCB version, protocol and software version of the subprocessor.

Device parameters-MAC: 00009289/LOC: 00009289 Modul KNX1 ver: 5.0.0.6847	_	×
🕘 Basic 📘 FLAGS Bin 📶 Translacje		
Virtual MAC Prefix 02		
Area: Line: Dev: KNX Addres: 1 7		
KNX bridge data: PCB: 3 SOFT: 19 PROTO: 1		
📩 Load 🕞 Set default 📩 Send		
		.::

Conversions from the KNX bus to CAN bus

In the *Conversions* window, there are two tabs, in which you can configure information conversion between buses.

	Devi	ce parameters-MAC: 0000F647/LOC: 0000F647	ver: 5.0.0.6822	_	×
(🕅 Bas	sic 📘 FLAGS Bin 📶 Conversions			
K	(NX to	CAN CAN to KNX			
	List of	f conversions			
[On	KNX	CAN		
	1	CF:00 Dev:0.0.0,Grp:[0],DType:[Bool]	CANSuf: 01DType: 00 Br: 0F ValNo: 01	-	
				8	
				+	
				1	
	-	Load 🕞 Set default	📥 Send		
L]	

Using the right buttons, you can add, edit, or remove conversions from the list. After adding a conversion, you will see a window with its settings.

Conversion window	KNX -> CAN			_		×
Data in KNX:		Data in CAN:				
Control field:	00 HEX	CAN suffix:	01 HEX			
Physical address:	Area: Line: Dev:	Type of data:	Binary			\sim
Group address type:	Eree 16h	Type of frame:	0x0F Inputs, binary outputs			\sim
Group address type.	Main:	Value number	1			\sim
Group address:	0					
Data type:	Binary 1 bit 🗸 🗸					
			Confirm	Δ	Cancel	

Control field should be left at default, addresses copied from the KNX project and the right *Data type* should be selected. Next, determine how data should be transmitted to the CAN bus. Change the editable part of the address (suffix) and configure the *Data type*, *Information type* and *Value number* (one device in the CAN bus can send e.g. 3 temperature values in one frame), and confirm. When you are done, remember to send the new lists to the device.

In order to create conditions for KNX devices, you must add a virtual device in the configurator (with an address in the following format: 1100PPAA, where PP is a prefix from *Device parameters*, and AA is a suffix from particular translations; the exact address can also be viewed in the *Network monitor*). The process of adding such a device is described in the Virtual devices guide. Having added such a device, you can create conditions from the virtual device, which will transmit information from the KNX bus. To achieve this, enter the *Device configurator* of the target module, select the virtual device from the next list and click *Add condition from device*.

诸 Ci	onfigur	ation win	dow of act	uating device								
List o	ist of online devices: Device configuration- Type: U047-M-CON-KNX-s, MAC 009289, Modul KNX1											
Se	Search for devices: Device name V											
On	M	AC	Local	▲ Type		Name				Pcb	Soft	Buffer
1	11	000101	11000101	U000 VIRTUAL		KNX_IN						
2	92	89	9289	U047 M-CON-K	NX-s	Modul KNX1				1	2	1024
Т	he cono	dition-M/	AC: 1100010	01/LOC: 110001	01 KNX_IN ver: 5.0.0).6847						
111	The de	efinition	of forcin	g informatio	n. Warning!!! in	this windo	ow, we on	ly mark v	vhat we w	ant to r	espond to.	
	💼 Inp	uts/Outpu	uts 🖓 Lin	ear output 🏹	Linear inputs	Flags Bin F	8 Flags lin 8b	it <mark>F16</mark> Fla	in 16bit	BS 18E	320	
	Input	s:						Outputs	s:			
	> 1		2		3	4		> 1		2		3
		Act		Act	Act		ct		ct	A	at 🗌 [Act
	5		6		7	8		5		6		7
		Act		Act	Act		ct	A	ct	A	t [Act

If you want the virtual device to be visible on the list on the next launch of the configurator, save the project by going to the *Project* tab and click *Save project*. You will then open the saved project with the next launch of the application.

Conversions from the CAN bus to KNX

In the second tab, you can configure conversions from the CAN bus to the KNX bus.

	Devid	e parameters-MAC: 0000F647/LOC: 0000F647 v	er: 5.0.0.6822	_	×
	💽 Basi	ic FLAGS Bin III. Conversions			
	KNX to	CAN CAN to KNX			-
	List of	conversions			
	On	CAN	KNX	1	
	1	Dev: 0000390E DType: Bin Br: 0F ValNo: 1	CF:00,Com:00,Adr:[3],DType:[Bool Par: 00]	+	
				-	
S	2	Load C Set default	📩 Send		

Add a new conversion, set its parameters, and add a full CAN *Device address*. Then choose what *Data type*, *Information type* and *Value number* you want to transmit. On the KNX side leave *Control field* and *Command* at default. Then select the address with which data will be sent to the bus, determine the *Data type* and *Parameter* if needed.

For binary inputs/outputs there is a possibility of configuring reactions to the signal slope (from subprocessor software no. 13). In accordance with descriptions, you can define reactions to an increasing slope and a decreasing slope. The reactions can be as follows: sending 1, sending 0, or no reaction (marked as -).

Some of the data types are sent from the CAN bus in multiple frames (selected in the *Type of frame* field). Because of that, if you want to e.g. select the temperature sensor no. 4 from an Ampio module, you must set the *Type of data* as *Exact temperature*, *Type of frame* as *0x07 2-byte temperature*, and *Value number* as 1.

Conversion window CAN -> KNX				
Data in CAN:			Data in KNX:	
Device address	00000001 HEX		Control field:	00 HEX
Type of data:	Binary	~	Command:	00 HEX
Type of frame:	0x0F Inputs, binary outputs	~	Group address type:	Free - 16b 🗸 🗸 🗸
Value number	1	~		Main:
Retransmit value:	Minimal period [s]:	250	Group address:	0
	L		Data type:	Binary 1 bit \vee
			Parameter:	Rise -> 1 Fall -> 0
			🕑 Confin	m 🛕 Cancel

From now on, data from the CAN bus will be visible in the KNX bus. If you would like to check how everything is working, you can use e.g. nie ETS application and the *Diagnostics* tab.

From the configurator version 5.0.0.7291, there is a possibility of regular transmission of data from the CAN to the KNX bus, even if values have not changed. For the function to work properly, the secondary processor must be of at least version 31 (info displayed in the *Basic* tab). Time that can be set for the module ranges from 10 to 250 seconds.

In order to add a condition from binary **outputs** in the CAN system, you should select "Binary" *Data type*, "0x0F Inputs, binary outputs" in the *Type of data* and add 24 to the output's value (max. number of inputs). For example, for output no. 1, select type 0x0F, value number 25, and for output no. 2, select type 0x0F and value number 26, etc.