

WL-REL-2p: Wireless module with two relay outputs

Document number: PO-047-EN Version: 1.4.0 Date of publication: August 22, 2025



Technical data

Supply voltage
110 – 250V AC

Idle power consumption
0.8W

Number of relay outputs
2

Maximum AC current of a single relay output ($\varphi \approx 0$)
10A

Maximum total current of all relay outputs
16A

Technical data cont.

Wireless range indoors
300m

Wireless range outdoors
1km

Number of AC inputs
2

AC inputs voltage
110 – 250V AC

Dimensions

Width
48mm

Height
48mm

Depth
22.5mm

Environment

Temperature
-40 – 50°C

Humidity
≤95%RH, non-condensing

The image above is for illustration purpose only. The actual module may vary from the one presented here.

General features

Module WL-REL-2p is a component of the Ampio system. Required voltage to power the module is 110 – 250V AC. The module is controlled via the Ampio LoRa wireless interface.

The module has two relay outputs and two AC inputs.

Relay outputs

The module has relay outputs that enable switching on resistive and inductive loads. The module relays are normally open. The table below shows the permissible operating parameters of the relays depending on the nature of the load.

The nature of the load	Maximum long-term permissible current
AC1: Resistive or moderately inductive AC loads	10A
AC15: Inductive AC loads	1.5A

One of the contacts of each of the relays is connected to the power phase of the module.

The module outputs are not intended for controlling sockets due to the possibility of connecting a receiver that exceeds the current capacity of the module. It is possible to connect the module to a socket after connecting it to an external contactor.

AC inputs

The module has inputs that go into an active state when they are connected to an alternating voltage in the range of 110 – 250V AC. These inputs can be useful for phase presence detection or integration with devices with AC outputs, e.g.

PIR or microwave presence detectors. They can also be used to connect classic light switches or other devices with potential-free contact outputs.

Typical application

- Switching on the lighting;
- control of motor devices;
- connecting classic light switches or other devices with potential-free contact outputs;
- integration with devices with potential-free relay outputs;
- phase presence detection;
- integration with devices with AC outputs.

Installation

The dimensions of the module enable its installation in a standard junction box. In order to start it up, it must be connected to the power supply and paired with the module acting as an Ampio LoRa base station in the wired segment of the building automation installation.

The module has a connector with screw terminals. It allows one to connect the device's power lines, signal lines to AC inputs, and loads of relay outputs.

One of the contacts of each of the relays is connected to the power phase of the module.

Device status LEDs

On the front of the module there are signalling LED diodes. The green LED with the label *STATUS* indicates the status of communication on the Ampio LoRa interface.

Programming

The programming of the module is executed using the [Ampio Designer](#) tool. It allows modifying the module's parameters and defining its behaviour in response to signals directly available to the module. It also provides access to all the information coming from all the devices present within the building automation bus.

Before starting configuration activities, it is necessary to pair the device with the module acting as the Ampio LoRa base station in the wired part of the building automation installation. To do this, using the Ampio Designer software, put the base station module into search mode for modules from the WL group. While the search mode is active, press the pairing button three times on the activated radio module. If the operation is successful, the found device will appear in the list of paired wireless modules in the Ampio Designer software.

It is not recommended to use more than 8 Ampio LoRa wireless modules per one base station module. Installing more modules may result in excessive load on the wireless network and improper functioning of the system.

Programming the rules for which the WL-REL-2p module is to be an executive device, is defined during the configuration of the base station module. In order to create rules whose triggering depends on the state of the WL-REL-2p module, it is necessary to add it to the device list as a *virtual device*.

Inputs state broadcasting

By default, the inputs status of the WL-REL-2p device is not broadcast within the wired part of the building automation bus installation. This behavior can be modified using the Ampio Designer configurator software, as part of the configuration of the device parameters available in the module settings of the Ampio LoRa base station.

Internal rules

Internal rules of the module, i.e. the rules whose triggering depends on the state of the module's own inputs, while their outcome applies to the module's own outputs, are defined within the parameters of the module. Modification of the WL-REL-2p device parameters is possible in the settings of the Ampio LoRa base station with which the device is associated.


By default, each WL-REL-2p module implements the following internal rules:

- triggering input 1 changes the state of relay output 1,
- triggering input 2 changes the state of relay output 2.

These rules can be removed or modified at the device's configuration stage.

Module dimensions

Dimensions expressed in millimeters.



Connection diagram

